

## DC100 / DC150 / DC200 / DC300 / DC400 / DC600 / DC900 使用說明

1. 先將電源線接至單相 AC110V 或 AC220V 插座 . (以機器後方貼紙標示為準)
2. 將工件置入清洗籃內,再放入水槽內.
3. 按下電源鍵 POWER (ON / OFF), SET TIME 燈亮依工件髒污程度按設定鍵 SET (▲ / ▼) 上下自行增減清洗時間可由 1~99 分鐘自行調整, 俱倒數功能 (如需連續洗淨時設定 " 0 " ), 設定完成按下超音波鍵 SONICS (START / STOP) 即可開始作動, 洗淨中欲停止按下超音波鍵 SONICS (START / STOP) 即可 .
4. 停機不用時關閉電源鍵 POWER (ON / OFF) 即可 .
5. 當停電或將電源線拔除時, 前次清洗時間設定無法保留, 需重新設定 .

### Specification / 規格

Model (機型)	DC100 / DC100H
Tank Size (水槽尺寸)	300 × 160 × 100 mm ( L × W × H )
Overall Size (外型尺寸)	330 × 205 × 280 mm ( L × W × H )
Tank Capacity (水槽容積)	4.8 L
Frequency (振盪頻率)	40 KHz
Tank Material (水槽材質)	SUS 304 # 1.2 mm
Overall Material (外觀材質)	SUS 304 # 0.8 mm
Cover Material (上蓋材質)	SUS 304
Output Power (洗淨出力)	100 W
Timer (定時器)	Continuous ( " 0 " ) & 99 min.
Heater (加熱器)	150W ( DC100H only then has this equipment )
Temp.Setting (溫度設定)	Highest 80 °C (DC100H only has this function)
Basket Size (洗籃尺寸)	280 × 135 × 60 mm ( L × W × H )
Power Supply (使用電源)	AC100 ~ 120V / 60Hz or AC220 ~ 240V / 50Hz
Net Weight (淨重)	5 kg

### Specification / 規格

Model (機型)	DC200 / DC200H
Tank Size (水槽尺寸)	300 × 240 × 150 mm ( L × W × H )
Overall Size (外型尺寸)	330 × 285 × 330 mm ( L × W × H )
Tank Capacity (水槽容積)	10.8 L
Frequency (振盪頻率)	40 KHz
Tank Material (水槽材質)	SUS 304 # 1.5 mm
Overall Material (外觀材質)	SUS 304 # 0.8 mm
Cover Material (上蓋材質)	SUS 304
Output Power (洗淨出力)	200 W
Timer (定時器)	Continuous ( " 0 " ) & 99 min.
Heater (加熱器)	250 W (DC200H only then has this equipment )
Temp.Setting (溫度設定)	Highest 80 °C (DC200H only has this function )
Basket Size (洗籃尺寸)	260 × 220 × 100 mm ( L × W × H )
Power Supply (使用電源)	AC100 ~ 120V / 60Hz or AC220 ~ 240V / 50Hz
Net Weight (淨重)	9.5 Kg

### Specification / 規格

Model (機型)	DC400 / DC400H
Tank Size (水槽尺寸)	500 × 300 × 200 mm ( L × W × H )
Overall Size (外型尺寸)	530 × 345 × 380 mm ( L × W × H )
Tank Capacity (水槽容積)	30 L
Frequency (振盪頻率)	40 KHz
Tank Material (水槽材質)	SUS 304 # 1.5 mm
Overall Material (外觀材質)	SUS 304 # 0.8 mm
Cover Material (上蓋材質)	SUS 304
Output Power (洗淨出力)	400 W
Timer (定時器)	Continuous ( " 0 " ) & 99 min.
Heater (加熱器)	500 W (DC400H only then has this equipment )
Temp.Setting (溫度設定)	Highest 80 °C ( DC400H only has this function )
Basket Size (洗籃尺寸)	445 × 270 × 135 mm ( L × W × H )
Power Supply (使用電源)	AC100 ~ 120V / 60Hz or AC220 ~ 240V / 50Hz
Net Weight (淨重)	18.5 kg

### Specification / 規格

Model (機型)	DC600 / DC600H
Tank Size (水槽尺寸)	500 × 300 × 300 mm ( L × W × H )
Overall Size (外型尺寸)	530 × 345 × 480 mm ( L × W × H )
Tank Capacity (水槽容積)	45 L
Frequency (振盪頻率)	40 KHz
Tank Material (水槽材質)	SUS 304 # 1.5 mm
Overall Material (外觀材質)	SUS 304 # 0.8 mm
Cover Material (上蓋材質)	SUS 304
Output Power (洗淨出力)	600 W
Timer (定時器)	Continuous ( " 0 " ) & 99 min.
Heater (加熱器)	1000W ( DC600H only then has this equipment )
Temp.Setting (溫度設定)	Highest 80 °C ( DC600H only has this function )
Basket Size (洗籃尺寸)	435 × 270 × 135 mm ( L × W × H )
Power Supply (使用電源)	AC100 ~ 120V / 60Hz or AC220 ~ 240V / 50Hz
Net Weight (淨重)	22 Kg

## DC100 / DC150 / DC200 / DC300 / DC400 / DC600 / DC900

### Instructions for use

1. First connect the power cord to the single-phase AC110V or AC220V socket. (See the sticker on the back of the machine)
2. Place the workpiece into the cleaning basket and then into the tank.
3. Press the power button POWER (ON / OFF), the SET TIME light turns on press the SET button SET (▲ / ▼) up and down to increase or decrease the cleaning time. The cleaning time can be adjusted from 1 to 99 minutes it has a countdown function (set " 0 " if continuous washing is required), after setting press the ultrasonic key (START / STOP) to start operation, to stop washing, press the ultrasonic key SONIC (START / STOP) is enough.
4. Just turn off the POWER (ON / OFF) button when the machine is not in use.
5. When there is a power outage or the power cord is unplugged, the previous cleaning time setting cannot be retained and needs to be reset.

### Specification / 規格

Model (機型)	DC150 / DC150H
Tank Size (水槽尺寸)	300 × 160 × 150 mm ( L × W × H )
Overall Size (外型尺寸)	330 × 205 × 330 mm ( L × W × H )
Tank Capacity (水槽容積)	7.2 L
Frequency (振盪頻率)	40 KHz
Tank Material (水槽材質)	SUS 304 # 1.5 mm
Overall Material (外觀材質)	SUS 304 # 0.8 mm
Cover Material (上蓋材質)	SUS 304
Output Power (洗淨出力)	150 W
Timer (定時器)	Continuous ( " 0 " ) & 99 min.
Heater (加熱器)	250 W ( DC150H only then has this equipment )
Temp.Setting (溫度設定)	Highest 80 °C ( DC150H only has this function )
Basket Size (洗籃尺寸)	280 × 130 × 100 mm ( L × W × H )
Power Supply (使用電源)	AC100 ~ 120V / 60Hz or AC220 ~ 240V / 50Hz
Net Weight (淨重)	8 Kg

### Specification / 規格

Model (機型)	DC300 / DC300H
Tank Size (水槽尺寸)	300 × 240 × 150 mm ( L × W × H )
Overall Size (外型尺寸)	330 × 285 × 330 mm ( L × W × H )
Tank Capacity (水槽容積)	10.8 L
Frequency (振盪頻率)	40 KHz
Tank Material (水槽材質)	SUS 304 # 1.5 mm
Overall Material (外觀材質)	SUS 304 # 0.8 mm
Cover Material (上蓋材質)	SUS 304
Output Power (洗淨出力)	300 W
Timer (定時器)	Continuous ( " 0 " ) & 99 min.
Heater (加熱器)	250 W (DC300H only then has this equipment )
Temp.Setting (溫度設定)	Highest 80 °C (DC300H only has this function )
Basket Size (洗籃尺寸)	260 × 220 × 100 mm ( L × W × H )
Power Supply (使用電源)	AC100 ~ 120V / 60Hz or AC220 ~ 240V / 50Hz
Net Weight (淨重)	10.5 Kg

### Specification / 規格

Model (機型)	DC600 / DC600H
Tank Size (水槽尺寸)	500 × 300 × 200 mm ( L × W × H )
Overall Size (外型尺寸)	530 × 345 × 380 mm ( L × W × H )
Tank Capacity (水槽容積)	30 L
Frequency (振盪頻率)	40 KHz
Tank Material (水槽材質)	SUS 304 # 1.5 mm
Overall Material (外觀材質)	SUS 304 # 0.8 mm
Cover Material (上蓋材質)	SUS 304
Output Power (洗淨出力)	600 W
Timer (定時器)	Continuous ( " 0 " ) & 99 min.
Heater (加熱器)	500 W (DC600H only then has this equipment )
Temp.Setting (溫度設定)	Highest 80 °C ( DC600H only has this function )
Basket Size (洗籃尺寸)	445 × 270 × 135 mm ( L × W × H )
Power Supply (使用電源)	AC100 ~ 120V / 60Hz or AC220 ~ 240V / 50Hz
Net Weight (淨重)	19.5 kg

### Specification / 規格

Model (機型)	DC900 / DC900H
Tank Size (水槽尺寸)	500 × 300 × 300 mm ( L × W × H )
Overall Size (外型尺寸)	530 × 345 × 480 mm ( L × W × H )
Tank Capacity (水槽容積)	45 L
Frequency (振盪頻率)	40 KHz
Tank Material (水槽材質)	SUS 304 # 1.5 mm
Overall Material (外觀材質)	SUS 304 # 0.8 mm
Cover Material (上蓋材質)	SUS 304
Output Power (洗淨出力)	900 W
Timer (定時器)	Continuous ( " 0 " ) & 99 min.
Heater (加熱器)	1000W ( DC900H only then has this equipment )
Temp.Setting (溫度設定)	Highest 80 °C ( DC900H only has this function )
Basket Size (洗籃尺寸)	435 × 270 × 135 mm ( L × W × H )
Power Supply (使用電源)	AC100 ~ 120V / 60Hz or AC220 ~ 240V / 50Hz
Net Weight (淨重)	24 Kg